


QR-Code

The menu item **QR-Code** allows you to create QR-Codes for use with FAAC barrier systems.



To create a QR-Code, follow these steps:

1. Enter a period in the fields *Valid from* and *Valid to* during which the QR-Code should be valid.
2. In the field *Number of uses*, enter the number of times the QR-Code can be used within the validity period.
3. The field *Initial String* indicates for which barrier system the QR-Code is created. If there are several barrier systems, select the desired system.
4. (Optional) In the area *Additional Data for Printout*, enter a comment to appear on the printout. Select *Print validity information* if you want the number of uses and the validity period to appear on the printout as well.
5. Press *Generate QR-Code* to generate the document.
6. Press *Print* to print the document.

TIPS

You can create additional barrier systems via the menu item *Settings* in the visitor management.

Revision #5

Created 2024-11-27 09:57:32 UTC by DRAKOS

Updated 2025-10-06 10:01:22 UTC by DRAKOS